
PrevenzTM microbial Wheels

Helps control bacteria, molds, mildew, fungi and odors





WITHOUT PREVENZ™

WITH PREVENZ™

Above photos show the difference in bacterial growth over a seven day incubation period.



www.albioninc.com



Applications

- Scientific and Research
- Medical and Healthcare
- Pharmaceutical
- Chemical
- Food processing
- Clean rooms
- Any application where controlling microbes is important

The Prevenz Story

How Does Prevenz™ Work?

The antimicrobial compound used in Prevenz[™] wheels is designed to suppress the growth of a variety of destructive and odor causing microbes including bacteria, molds, mildew, and fungi. The active ingredients neutralize the ability of microbes to function, grow and reproduce.

How long does the protection last?

Prevenz[™] is engineered

to be effective against microbes for the life of the wheel. The agent MEDICAL remains stored in the polymer and is gradually

released to the surface of the wheel.

Will scratches, tread wear or wax buildup diminish the effectiveness?

No. Prevenz[™] protection is not a coating on the surface of wheel. It is an integral part of the wheel material. Abrasion, chips or scratches will not impact the effectiveness of Prevenz™ in any way. Not even wax buildup on the wheel can impair the bacteria fighting performance.



Does Prevenz™ eliminate the need for cleaning?

No. Although Prevenz™ provides an added level of protection, these wheels do not eliminate the need for normal cleaning practices. They are designed to work in conjunction with and enhance your ongoing program. Good hygiene

practices should always be observed.

Is Prevenz™ safe?

Yes. The active ingredients in Prevenz[™] have undergone extensive laboratory testing and have been proven safe.

The active ingredient has a history of hospital use for more than 25 years and is used in a broad range of popular personal care products, such as antimicrobial soap, toothpaste and deodorant. It is registered with the US

Environmental **Protection Agency** (EPA), and products with this material have been approved by the US Food & **Drug Administration** (FDA), the European

Union (EU), the National Sanitation Foundation (NSF) and other regulatory authorities around the world.

FOOD INDUSTRY

Features

- Suppresses growth of microbes
- Helps control bacteria, molds, mildew, fungi and odors
- Lasts the functional life of the product
- Reduces wheel decay and deterioration
- Resists color fading and discoloration to retain attractive appearance
- Complete line of Prevenz™ wheels





Albion Prevenz[™] wheels combat bacteria without compromising performance. Rolling resistance is extremely low making Prevenz[™] wheels some of the easiest to roll in the market. The tread is extremely durable, yet it rolls much quieter than hard plastic or metal wheels. Plus, it is non-marking and offers excellent floor protection. Prevenz[™] is right at home in even the harshest environments and offers excellent resistance to damage from water, chemicals, solvents and

petroleum products. You can easily identify these wheels by the attractive Prevenz[™] blue tread.

Prevenz™ XP (Solid Polyurethane)



Wheel Diameter (Inches)	Tread Width (Inches)	Capacity (Rated for Manual Operation)	Hub Length (Inches)	Bore ID (Inches)	Bearing ID (Inches)	Approx. Weight (Lbs)	Wheel Number With Precision Ball Bearing
4	2	1400	2 7/16	1 3/16	1/2	1	XP0422808 PREV
5	2	1200	2 7/16	1 ³ /16	1/2	1 1/2	XP0522808 PREV
6	2	1400	2 7/16	1 ³ /16	1/2	1 3/4	XP0622808 PREV
8	2	1200	2 ⁷ /16	1 ³ /16	1/2	4	XP0822808 PREV
8	2 1/2	2000	3 1/4	1 ¹⁵ /16	3/4	4	XP0842812 PREV
8	3	2000	3 1/4	1 15/16	3/4	4	XP0852812 PREV
10	2 1/2	2500	3 1/4	1 ¹⁵ /16	3/4	8	XP1042812 PREV
10	3	2500	3 1/4	1 15/16	3/4	8	XP1052812 PREV

To order 2-Piece Delrin Bearing change 6th and 7th digit to "51". Hub length is 2-3/16, bearing ID is 3/4". Not available for 2-1/2" or 3" tread width models.

To order Roller Bearing change 6th and 7th digit to "01". Hub length is 2-3/16, bearing ID is 3/4". Not available for 2-1/2" or 3" tread width models. Roller bearings come complete with spanner bushing & nylon sealed retaining thrust washers.



Prevenz™ XB (Polyurethane Tread)

	Wheel Diameter (Inches)	Tread Width (Inches)	Capacity (Rated for Manual Operation)	Hub Length (Inches)	Bore ID (Inches)	Bearing ID (Inches)	Approx. Weight (Lbs)	Wheel Number With Delrin Bearing
ı	3	1 3/8	300	1 1/4	15/16	1/2	3/8	XB0305108 PREV
ı	3 1/2	1 3/8	360	1 1/4	15/16	1/2	3/8	XB03X5108 PREV
ı	4	1 ³ /8	400	1 1/4	15/16	1/2	1/2	XB0405108 PREV
۱	5	1 3/8	440	1 ³ /8	15/16	1/2	3/4	XB0505108 PREV



Prevenz™ XA (Polyurethane Tread)

	Wheel Diameter (Inches)	Tread Width (Inches)	Capacity (Rated for Manual Operation)	Hub Length (Inches)	Bore ID (Inches)	Bearing ID (Inches)	Approx. Weight (Lbs)	Wheel Number With Roller Bearing
ı	4	2	600	2 3/16	1 3/16	3/4	1/2	XA0420112 PREV
ı	5	2	750	2 3/16	1 3/16	3/4	1 3/8	XA0520112 PREV
ı	6	2	900	2 3/16	1 3/16	3/4	2 1/2	XA0620112 PREV
ı	8	2	1000	2 ³ /16	1 ³ /16	3/4	2 3/4	XA0820112 PREV
	10	2 1/2	1500	3 1/4	1 15/16	1	3	XA1040116 PREV

Roller bearings come complete with spanner bushing & nylon sealed retaining thrust washers.

